



Yeastar 4G LTE Module for S-Series VoIP PBX

4G LTE Module provides full voice capabilities, high speed data transmission for S-Series VoIP PBX, supporting 3G/4G network standard, VoLTE*, and powerful SMS features.

❖ Specifications

Module	4G LTE Module			
Type	4G LTE Module-E	4G LTE Module-A	4G LTE Module-AU	4G LTE Module-CE
Network Type	UMTS (WCDMA) 3G / LTE			
Frequency	LTE FDD: B1/B3/B5/B7/B8/B20 LTE TDD: B38/B40/B41 WCDMA: B1/B5/B8 GSM: B3/B8	LTE FDD: B2/B4/B12 WCDMA: B2/B4/B5	LTE FDD: B1/B2/B3/B4/B5/B7/B8/B28 LTE TDD: B40 WCDMA: B1/B2/B5/B8 GSM: B2/B3/B5/B8	LTE FDD: B1/B3/B5/B8 LTE TDD: B38/B39/B40/B41 WCDMA: B1/B8; TD-SCDMA: B34/B39 CDMA2000 1X/EVDO: BC0 GSM: 900/1800
SMS	Yes			
MMS	No			
Voice Call	3G/4G Voice Call			
SIM Card	3G/4G Standard SIM Card			
Data	3G/4G Data (cannot be used as a 4G router)			
3G Data Speed	Max 384 Kbps (DL) / Max 384 Kbps (UL)			
LTE Data Speed	LTE-FDD: Max 150 Mbps (DL) / Max 50 Mbps (UL); LTE-TDD: Max 130 Mbps (DL) / Max 35 Mbps (UL)			
Module Insertion (LTE Data)	S412: T_Slot3; S20&S50: Module Slot 1; S100&S300: Module Slot 1, Expansion Board 1			
Module Insertion (LTE Voice)	S412: T_Slot3 or T_Slot4; no place limitation for S20/S50/S100/S300			
Call Waiting	No			
Call Forward	Yes			
RF Cable	Insert on MAIN T1 of the 4G LTE module.			
Antenna	The 4G LTE module can be used with one RF cable and one antenna. (To strengthen signal, 2 RF cables can be installed but 2 antenna ports will also be occupied with the exception of S20.)			
Model	S412, S20, S50, S100, S300 (Version 30.4.0.25 or higher)			

Click [here](#) to check the supported cellular operators.

*Please check with your operator to see if they support VoLTE and about the cost of VoLTE.